

# Original User Manual

## Series Industrial PC



Christ Electronic Systems GmbH

Alpenstraße 34

87700 Memmingen

04/2023

[www.christ-es.com](http://www.christ-es.com)

# Instruction Manual: Industrial PC

<b>1</b>	<b>Identification</b>	<b>4</b>
<b>2</b>	<b>Product description</b>	<b>6</b>
2.1	System Overview	7
2.2	Housing Variant Industrial PC	8
<b>3</b>	<b>Description Hardware</b>	<b>9</b>
3.1	External Interfaces	9
3.2	Add-On	14
3.2.1	UPS (Uninterruptible Power Supply)	14
<b>4</b>	<b>Assembly and Commissioning</b>	<b>15</b>
4.1	Torque	15
4.2	Connection of the power supply	16
4.3	Earth Connection	16
4.4	Mounting Industrial PC	16
4.5	Dismounting Industrial PC	17
<b>5</b>	<b>Accessories and Spare Parts</b>	<b>18</b>
5.1	Power supply	18
<b>6</b>	<b>Software</b>	<b>19</b>
6.1	BIOS Basic Settings	19
6.1.1	COM Port configuration	20
6.1.2	Set Boot Priority	20
6.2	BIOS Update	22
6.2.1	Preparation	22
6.2.2	Perform Update	22
6.3	OBS Client	24
6.3.1	Activating the OBS Client	24
6.3.2	Functions of the OBS Client	24
6.4	Redo Backup and Recovery	25
6.5	Enhanced Write Filter EWF	25
<b>7</b>	<b>Maintenance</b>	<b>26</b>
7.1	Cleaning	26
7.2	Maintenance	26
<b>8</b>	<b>Technical Data</b>	<b>27</b>
8.1	Mechanical Specifications	27

# Instruction Manual: Industrial PC

8.2	Electrical Specifications	27
8.3	Power Consumption	27
8.4	Electromagnetic Compatibility	28
8.5	Environmental Conditions	28
8.6	Temperature test	29
8.7	IP Protection Class	29
<b>9</b>	<b>Standards and Approvals</b>	<b>30</b>
9.1	CE Marking	30
9.2	RoHS	30
9.3	Electromagnetic Compatibility	30
9.4	Environmentally Appropriate Disposal	30
<b>10</b>	<b>Technical Support</b>	<b>31</b>
10.1	Device Seal	31

# Instruction Manual: Industrial PC

## 1 Identification

### Target group

This document is not intended for end customers! Necessary safety instructions for the end customer must be passed on by the machine builder or system provider and adopted in the respective national language.

### Intended use

The devices described in this documentation are intended to enable the user to control, operate, observe, drive and visualise certain processes.

### Technical changes

Christ Electronic Systems GmbH reserves the right to change the information, designs and technical data contained in this documentation without prior notice.

### History

The following editions of the manual have already been published:


Version	Comment
09/2021	First edition
03/2023	Redesign cover page Adjustments to the layout Chapter 1: Identification: Revision Chapter 2.3 Add-On: Moved, new chapter number 3.2 Chapter 3.1 External Interfaces: Note Signal and data cables included Chapter 3 Description Hardware, Chapter 7 Software, Chapter 8 Technical Data, Chapter 9 Standards and Approvals: Introductory sentence inserted Chapter 4.1 Temperature test: Moved, new chapter number 8.6 Chapter 4.2 IP Protection Class: Moved, new chapter number 8.7 Chapter 4.1 Torque: inserted Chapter 7 Maintenance: Note Loss of IP protection class inserted Chapter 7.1 Cleaning: Note exchanged Chapter 8.2 Electrical Specifications: improved supply voltage Chapter 8.5 Environmental Conditions: Ambient Temperature instead of Operating Temperature Chapter 8.6 Temperature test: Ambient Temperature instead of Operating Temperature Chapter 9.1 CE Marking: Note Declaration of Conformity removed


Table 1: History


# Instruction Manual: Industrial PC

## Design of safety instructions

<b>⚠ DANGER</b>	
	<p><b>Indicates an imminent danger</b> Failure to follow the instructions may result in death or serious injury.</p>

<b>⚠ WARNING</b>	
	<p><b>Indicates a dangerous situation</b> Failure to follow the instructions may result in serious injury.</p>

<b>⚠ CAUTION</b>	
	<p><b>Indicates a possible dangerous situation</b> Failure to follow the instruction may result in injury.</p>

<b>NOTICE</b>	
	<p><b>Indicates user tips and useful information</b> Important information to avoid malfunctions.</p>

# Instruction Manual: Industrial PC

## 2 Product description

Industrial PCs, as the heart of the machines in control cabinets, ensure smooth operation. The requirements placed on them are very different. For this reason, we offer our customers numerous product variants.

For a particularly long lifetime, there are no moving parts in the Industrial PCs. The Box PCs with passive cooling are therefore also particularly suitable for harsh industrial environments. Another advantage is the industrial-grade components that are available over a long period of time. The optional integrated UPS prevents data loss during power fluctuations. If the power fails, the devices are shut down properly.

The Industrial PCs can be loaded with either Windows or Linux before delivery and are then immediately ready for use.

Thanks to the compact housing design, Christ Industrial Computers can also be optimally used in confined spaces. Despite their small size, they deliver high performance when required.

Whether for IIoT applications or computing-intensive automation applications, the portfolio of industrial PCs meets a wide range of requirements. The processor performance classes Intel® Celeron® or Intel® Core™ i3, i5, or i7 are suitable for a wide range of applications.

Memory expansion is also possible without any problems.

# Instruction Manual: Industrial PC

## 2.1 System Overview

### Argon

CPU	Intel® Celeron™ N3350 1.1 GHz
Graphic	Intel® HD Graphics 500 200 Hz
Memory	1 x DDR3 Slot, max. 8 GB
BIOS	AMI Optio 5 BIOS
Interfaces	2 x USB 3.0 Port (Type A) 2 x 1 GBit Ethernet (RJ45) 1 x RS-232 / RS-422 / RS-485 (Bios setting) (RJ50) 1 x Display Port 1.0

Table 2: System overview Argon

### Titanium

CPU	Intel® Celeron™ 3965U 2.2 GHz	Intel® Core™ i3-7100U 2.4 GHz	Intel® Core™ i5-7300U 2.6 GHz	Intel® Core™ i7-7600U 2.8 GHz
Graphic	Intel® HD Graphics 610	Intel® HD Graphics 620		
Memory	2 x DDR4 slot, in summary max. 32 GB			
BIOS	AMI Optio 5 BIOS			
Interfaces	4 x USB: 2 x USB 2.0 Port (Type A); 2 x USB 3.0 Port (Type A) 2 x 1 GBit Ethernet (RJ45) 1 x RS-232 / RS-422 / RS-485 (Bios setting) (Sub-D) 1 x Display Port 1.1			

Table 3: System overview Titanium

# Instruction Manual: Industrial PC

## 2.2 Housing Variant Industrial PC




Illustration 1: Industrial PC

1	DIN Rail, 35 mm x 7.5 mm, DIN Rail 35 mm x 15 mm
2	Interface Area

Table 4: Industrial PC Front




Illustration 2: Dimensions Industrial PC

Architecture	A	B	C	D
Argon	180	130	33	90
Titanium	230	160	33	115

Table 5: Dimensions Industrial PC





# Instruction Manual: Industrial PC

## 3 Description Hardware

The description of the hardware refers to the device interfaces and the possible extensions for the device.

### 3.1 External Interfaces

<b>NOTICE</b>	
	<p><b>External cable for Power Supply, Signal or Periphery</b> Malfunction occur</p> <ul style="list-style-type: none"> <li>➤ Prepare a proper earth connection on the power supply</li> </ul>
<b>NOTICE</b>	
	<p><b>Signal and data cables</b> Malfunction occur</p> <ul style="list-style-type: none"> <li>➤ Signal and data cables must be shielded and of high quality.</li> </ul>

#### Supply Connector screwable


	<b>Mating Connector</b>	Phoenix Connector MC 1,5 / 3-STF-3.5 (screwable)	
	<b>PIN</b>	<b>Function</b>	<b>Description</b>
	1	GND	Ground
	2	FE	Functional Earth
	3	+24 VDC	Supply

Table 6: Pinout Supply Connector screwable

#### USB Host 2.0 (Type A)



	<b>PIN</b>	<b>Function</b>	<b>Description</b>
	1	VBUS	USB VCC
	2	D-	USB Data-
	3	D+	USB Data+
	4	GND	USB Ground

Table 7: Pinout USB 2.0

# Instruction Manual: Industrial PC


## USB Host 3.0 (Type A)



PIN	Function	Description
1	VBUS	USB VCC
2	D-	USB Data-
3	D+	USB Data+
4	GND	USB Ground
5	StdA_SSRX-	SuperSpeed transmitter differential pair
6	StdA_SSRX+	SuperSpeed transmitter differential pair
7	GND_DRAIN	Ground for signal return
8	StdA_SSTX-	SuperSpeed receiver differential pair
9	StdA_SSTX+	SuperSpeed receiver differential pair

Table 8: Pinout USB 3.0

## Ethernet



PIN	Function	Description
1	D1+	Transmit Data +
2	D1-	Transmit Data -
3	D2+	Receive Data+
4	D3+	Bidirectional +
5	D3-	Bidirectional -
6	D2-	Receive Data -
7	D4+	Bidirectional +
8	D4-	Bidirectional -

Table 9: Pinout Ethernet

## WLAN




Mating Connector	RP-SMA
Transmission Standard	802.11 ac/a/b/g/n (2.4 GHz, 5 GHz)

Table 10: Pinout WLAN

# Instruction Manual: Industrial PC

## Serial Connector (Titanium)




	RS-232		RS-422		RS-485	
PIN	Function	Description	Function	Description	Function	Description
1	DCD	Data Carrier Detect	TX-	Transmitter Differential Pair -	DATA-	Data Differential Pair A
2	RX	Receive Data	TX+	Transmitter Differential Pair +	DATA+	Data Differential Pair B
3	TX	Transmit Data	RX+	Receiver Differential Pair +	--	--
4	DTR	Data Transmit Ready	RX-	Receiver Differential Pair -	--	--
5	GND	Ground	GND	Ground	GND	Ground
6	DSR	Data Set Ready	--	--	--	--
7	RTS	Ready To Send	--	--	--	--
8	CTS	Clear To Send	--	--	--	--
9	RI	Ring Indicator	--	--	--	--

Table 11: Pinout Serial Connector Titanium

# Instruction Manual: Industrial PC

## Serial Connector (Celeron N3350 Argon)




PIN	RS-232		RS-422		RS-485	
	Function	Description	Function	Description	Function	Description
1	DSR	Data Set Ready	--	--	--	--
2	GND	Ground	GND	Ground	GND	Ground
3	GND	Ground	GND	Ground	GND	Ground
4	TXD	Transmit Data	RX+	Receiver Differential Pair +	--	--
5	RXD	Receive Data	TX+	Transmitter Differential Pair +	DATA+	Data Differential Pair B
6	DCD	Data Carrier Detect	TX-	Transmitter Differential Pair -	DATA-	Data Differential Pair A
7	DTR	Data Terminal Ready	RX-	Receiver Differential Pair -	--	--
8	CTS	Clear To Send	--	--	--	--
9	RTS	Request To Send	--	--	--	--
10	RI	Ring Indicator	--	--	--	--

Table 12: Pinout Serial Connector Celeron N3350 Argon

# Instruction Manual: Industrial PC

## Display Port



PIN	Function	Description
1	DP data 0+	DP data 0+
2	GND	Ground
3	DP data0-	DP data0-
4	DP data1 +	DP data1 +
5	GND	Ground
6	DP data1-	DP data1 -
7	DP data2+	DP data2+
8	GND	Ground
9	DP data2-	DP data2-
10	DP data3+	DP data3+
11	GND	Ground
12	DP data3-	DP data3-
13	CONFIG1 CAD	Cable adapter recognized
14	CONFIG2	Ground (Pull-Down)
15	AUX_CH+	Additional device +
16	GND	Ground
17	AUX_CH-	Additional device -
18	HPD	Hot Plug recognized
19	GND	Ground
20	DP_PWR 3,3V	Power Supply DP

Table 13: Pinout Display Port



With the DP1.0 it is not possible to display an image on DVI / HDMI devices. An active adapter with properties of DP++ is required for this.<sup>1</sup>



Display Port 1.1 is also known as "Dual-Mode Display Port" and "Display Port++". This allows compatibility with DVI and HDMI.

<sup>1</sup> The Argon board uses DP1.0

# Instruction Manual: Industrial PC

## 3.2 Add-On

In the following all extension possibilities are shown.

### 3.2.1 UPS (Uninterruptible Power Supply)

Energy Storage	400 Ws / 650 Ws
Charge Duration	90 % in 45 seconds 100 % in 80 seconds
Configuration	Shutdown Time Dimming Time Dimming Intensity

Energy storage value: see technical data sheet.

The instruction for the UPS can be found in the download section of the Christ website: [Downloads](#)

The device was operated with the following conditions: operating system Windows 10 IoT, no applications.

It must be ensured that the customer application is ended quickly enough for the IPC to shut down properly. Otherwise no protection against data loss or any other disfunction can be guaranteed. Depending on the CPU utilization and peripherals, the buffer time can be significantly shorter.

**The exact buffer duration must be determined anew in every system setup.**



Intel® Celeron™ 3965U	59 s
Intel® Core™ i3-7100U	57 s
Intel® Core™ i5-7300U	34 s
Intel® Core™ i7-7600U	38 s
Intel® Celeron™ N3350	99 s

Table 14: UPS buffer duration

# Instruction Manual: Industrial PC

## 4 Assembly and Commissioning

This chapter describes all the steps for assembly. The following warnings are safety instructions that must be applied throughout the assembly chapter and in every other life cycle of the device.

<b>⚠ DANGER</b>	
	<p><b>Danger from electric shock, explosion or electric arc</b> Serious injury or death</p> <ul style="list-style-type: none"> <li>➤ Pull out the mains plug and do not open the covers</li> </ul>
<b>⚠ WARNING</b>	
	<p><b>Dropping a device</b> Injuries and bruises to the legs and / or feet</p> <ul style="list-style-type: none"> <li>➤ Wear safety shoes</li> </ul>

### Note for the installation site

This device is not designed for outdoor use.

Make sure that the ambient temperature and humidity are within the ranges which are specified under [Environmental Conditions](#).

Do not install the device directly in the sunlight.

Make sure that the device is installed so that is accessible for the operator.

### Installation instructions

Check the package contents for any visible damage and for completeness.

In case of damage, do not install the device and contact the [Christ Service](#).

## 4.1 Torque

All screws must be tightened with a minimum torque.

Screw	Torque
M3	1 Nm
M4	2,3 Nm

# Instruction Manual: Industrial PC

## 4.2 Connection of the power supply

Use conductors with a cross-section of 0.75 mm<sup>2</sup> to 1.5 mm<sup>2</sup>. Use the MC 1,5/ 3-STF-3,5 BKBDWH:GND Q PCB connector from Phoenix.

Strip the insulation from the individual wires of the conductor (1). Insert these into the connection contacts (3) of the PCB connector and tighten the screw contacts (2) with a screwdriver and a maximum torque of 0.3 Nm.

The rear view (4) of the connector is shown for clarification.





Illustration 3: Connection of the power supply

## 4.3 Earth Connection

<b>NOTICE</b>	
	<p><b>Earthing not connected</b></p> <p>Not guaranteed functionality of the device</p> <p>➤ All earth connections must be connected to an earth point</p>

## 4.4 Mounting Industrial PC

### Step 1:

Hook the Industrial PC onto the fastening rail at an angle from above. Press the Industrial PC down until it hooks into place.




Illustration 4: Mounting Industrial PC Step 1

### Step 2:

The industrial PC hangs on the fastening rail.




Illustration 5: Mounting Industrial PC Step 2




# Instruction Manual: Industrial PC

## 4.5 Dismounting Industrial PC

**Step 1:**


Pull down on the pull cord to release the Industrial PC.



*Illustration 6: Dismounting Industrial PC Step 1*

**Step 2:**

Tilt the Industrial PC forward with the pull cord pulled at the bottom and unhook it at the top.




*Illustration 7: Dismounting Industrial PC Step 2*

# Instruction Manual: Industrial PC

## 5 Accessories and Spare Parts

The accessories listed here have been checked by Christ and are compatible with the products. The following accessories are available:

### 5.1 Power supply



<b>Input Voltage</b>	90 - 264 VAC
<b>Input Current</b>	max. 1 A
<b>Input Frequency</b>	47 - 63 Hz
<b>Consumption with unloaded output</b>	max. 0.075 W
<b>Output Voltage</b>	24 VDC
<b>Output Current</b>	max. 2.5 A
<b>Temperature Range Operation</b>	0 - 70°C
<b>Humidity Operation</b>	20 - 80% RH non condensing

Table 15: Power supply

# Instruction Manual: Industrial PC

## 6 Software

The Software chapter describes settings and functions that may be required to use the device.

The x86 architecture has a BIOS (Basic Input Output System) for the basic settings of the system. This is not present in the ARM architectures. Here, updates are performed with **CURT** (Christ Update and Recovery Tool).

### 6.1 BIOS Basic Settings

AMI BIOS ROM has built-in settings program that allows users to make basic settings. This information is stored in a battery supported CMOS RAM, so it remains stored even when there is no power supply.

Accessing the BIOS works by pressing the "Del" key several times while the device is booting.

The following tabs in the BIOS enable various settings.

<b>Main</b>	Set date
<b>Advanced</b>	Make advanced BIOS settings like: COM, ACPI, etc.
<b>Chipset</b>	Enter host bridge parameters
<b>Security</b>	Set administrator password
<b>Boot</b>	Set Boot Option
<b>Save &amp; Exit</b>	Save the settings made and initiate a restart. (Also possible with the F4 key on the keyboard)

Table 16: BIOS

Pressing F3 and confirming the query "Load Optimized Defaults?" with "Yes" restores the delivery state.




Illustration 8: BIOS

# Instruction Manual: Industrial PC

## 6.1.1 COM Port configuration

### COM Port configuration

#### Argon

In order for RS-232, RS-422 and RS-485 to be recognized on the COM port, the following settings must be made in the BIOS:

1. Select "Advanced" tab
2. Select "F81804 Super IO Configuration"
3. Select "Serial Port1 Configuration"
4. Make setting in "Device Mode" (RS-422 / RS-485 / RS-232)
5. Save with keystroke "F4" (confirmation with "Yes")

### COM Port configuration

#### Titanium

In order for RS-232, RS-422 and RS-485 to be recognized on the COM port, the following settings must be made in the BIOS:

1. Select "Advanced" tab
2. Select "F81804 Super IO Configuration"
3. Select "Serial Port1 Configuration"
4. Under "F81846 SERIAL PORT1 MODE SELECT" select the mode (RS232, RS422, RS485)
5. If RS422 or RS485 mode has been selected, settings can be made for "RS422/RS485 Termination" or "RTS Auto Flow Control"
6. Save with keystroke "F4" (confirmation with "Yes")




Illustration 9: BIOS COM Port Titanium

## 6.1.2 Set Boot Priority

### Set Boot Priority

#### Argon / Titanium

If you want to boot from a USB device, the following settings must be made in the BIOS:

# Instruction Manual: Industrial PC

1. Select "Boot" tab
2. Select "Boot mode select" "UEFI"
3. Open the "Boot Option #1" by pressing the "Enter" key
4. Select USB device with "Enter"
5. Save with keystroke "F4" (confirmation with "Yes")




Illustration 10: BIOS Boot Priority

# Instruction Manual: Industrial PC

## 6.2 BIOS Update

### 6.2.1 Preparation

Copy the AMI BIOS update files to a USB stick

You can obtain the required files from Christ Electronic Systems. These are the same for Argon and Titanium.

- efi
- flash.nsh
- fparts.txt
- Fpt.efi
- Titanium-200826a-S1M.bin (This .bin is only an example, the file can also be named differently)

### 6.2.2 Perform Update

Insert the bootable USB stick with the required files into the device.

Set the USB stick to Hard Disk Boot Priority in the BIOS. You can read about the procedure under [Boot Priority](#).

The EFI Update Script is automatically detected on the USB stick and starts the update process.

#### Further procedure Argon

- Confirm the question: "Enter 'q' to quit, any other key to continue:" with Enter.

```

If you don't want to update, press 'q', else press any key to update!
=====
Enter 'q' to quit, any other key to continue: _
    
```

*Illustration 11: Argon BIOS Update*

- Confirm the question "Do you want to continue? Y/<N> or q to quit:" with "y"
- The update is executed
- The message "FPT Operation Successful" indicates successful completion

```

FPT Operation Successful.
Done! Please turn off the system
    
```

*Illustration 12: Argon BIOS Update successful*

- Disconnect the power supply
- Restore the power supply and enter the BIOS again (do not reboot)
- Press the F3 key to confirm the question "Load Optimized Defaults" with "Yes"
- Press the F4 key to save and exit

#### Further procedure Titanium

Confirm the question: "Enter 'q' to quit, any other key to continue:" with Enter.

## Instruction Manual: Industrial PC

```
If you don't want to update, press 'q', else press any key to update!
=====
Enter 'q' to quit, any other key to continue: _
```

*Illustration 13: Titanium BIOS Update*

- The update is executed
- The message "FPT Operation Successful" indicates successful completion

```
FPT Operation Successful.
Done! Please turn off the system
```

*Illustration 14: Titanium BIOS Update successful*

- Disconnect the power supply
- Restore the power supply and enter the BIOS again (do not reboot)
- Press the F3 key to confirm the question "Load Optimized Defaults" with "Yes"
- Press the F4 key to save and exit

# Instruction Manual: Industrial PC

## 6.3 OBS Client

### 6.3.1 Activating the OBS Client

The OBS client is disabled by default.

To enable the OBS client, perform the following steps:

1. Launch Task Manager
2. Open "Startup" tab
3. Select "Hardware Monitor Utility for IBASE" and activate it by clicking on "Enable"




Illustration 15: Task Manager - enable OBS Client

4. Perform a restart of the device

### 6.3.2 Functions of the OBS Client

To start the OBS client, expand the taskbar and click on the key icon.




Illustration 16: Start OBS Client

These functions are provided by the OBS Client:

#### System Information

The System Information provides information about the processor and the operating system.




Illustration 17: OBS Client System Information



# Instruction Manual: Industrial PC

## Hardware Monitor

The Hardware Monitor category indicates the approximate temperatures of the processor and peripherals.




Illustration 18: OBS Client Hardware Monitor

## Settings

Various settings can be made in the Settings area.




Illustration 19: OBS Client Settings

## 6.4 Redo Backup and Recovery

The instructions for Christ Redo Backup and Recovery can be found in the Download section of the Christ website: [Downloads](#)


## 6.5 Enhanced Write Filter EWF

Instructions on how to set EWF and UWF filters can be found in the download section of the Christ website: [Downloads](#)


# Instruction Manual: Industrial PC

## 7 Maintenance

The following chapter describes maintenance measures that can be performed by a qualified end user.

<b>NOTICE</b>	
	<p><b>Seals attacked, damage to the housing</b> Loss of IP protection class</p> <ul style="list-style-type: none"> <li>➤ There must be no permanent exposure to substances containing large amounts of oils or fats.</li> </ul>

### 7.1 Cleaning

<b>NOTICE</b>	
	<p><b>Electronics may be damaged</b> Function of the Industrial PC disturbed</p> <ul style="list-style-type: none"> <li>➤ The device may only be cleaned when it is switched off or unplugged.</li> <li>➤ After cleaning, allow the Industrial PC to dry completely.</li> </ul>

To clean the device, use a soft cloth moistened with detergent solution.

The cleaning agent must not be applied directly to the device. Under no circumstances may aggressive solvents, chemicals or scouring agents be used.

### 7.2 Maintenance

It does not require any maintenance on the part of the user.

# Instruction Manual: Industrial PC

## 8 Technical Data

This chapter summarizes the technical data.

### 8.1 Mechanical Specifications

<b>Housing</b>	Aluminium
<b>Weight</b>	max. 1.2 kg
<b>Dimensions</b>	See Table Dimensions
<b>Mounting</b>	DIN Rail, 35 mm x 7.5 mm, DIN Rail 35 mm x 15 mm
<b>Cooling</b>	Passive

Table 17: Mechanical Specifications

### 8.2 Electrical Specifications


<b>Supply Voltage</b>	9,6 VDC ... 28,8 VDC
<b>Power Consumption</b>	see table Power Consumption
<b>Inrush Current (load-independent)</b>	max. 70A for 80 $\mu$ s (Used power supply: FSP060-DAAN3)
<b>External Power Supply</b>	SELV
<b>Earthing</b>	Functional Earthing (Cable cross-section has to be identical to the supply lines)
<b>Battery Lifetime</b>	4 years (constantly turned off)

Table 18: Electrical Specifications

### 8.3 Power Consumption

Architecture	Power Consumption
Argon	up to 25 W
Titanium	up to 45 W

Table 19: Power Consumption

<b>NOTICE</b>	
	<p><b>Specifications are maximum values</b> Peripheral devices are considered (e.g. 1 x USB 2.0 equals 2,5 W)</p>

# Instruction Manual: Industrial PC

## 8.4 Electromagnetic Compatibility

<b>Emitted Interference</b>	EN55032 Class A
<b>Immunity of supply line DC</b>	±2 kV according to IEC 61000-4-4; EFT ± 0,5 kV according to IEC 61000-4-5; Surge asymmetrical
<b>Immunity of signal lines</b>	±1 kV according to IEC 61000-4-4; EFT
<b>ESD</b>	± 4 kV Contact discharge according to EN61000-4-2 ± 8 kV Air discharge according to EN 61000-4-2
<b>Immunity of conducted emission</b>	3 V 150 kHz – 80 MHz, 80% AM nach IEC 61000-4-6
<b>Immunity of high-frequency radiation</b>	3 V/m 80 MHz – 1 GHz, 80% AM nach IEC 61000-4-3 3 V/m 1 GHz – 6 GHz, 80% AM nach IEC 61000-4-3

Table 20: Electromagnetic Compatibility


## 8.5 Environmental Conditions

<b>Ambient Temperature (Standard Conditions)</b>	0 ~ 50 °C
<b>Ambient Temperature (Different Conditions)</b>	0 ~ 60 °C (see device-specific datasheet)
<b>Storage Temperature</b>	-10 ~ 70 °C
<b>Humidity</b>	5 ~ 80 % (non condensing)
<b>Protection Class (Standard Conditions)</b>	IP20
<b>Transportation and Storage</b>	Suitable packing increases shock resistance
<b>max. Installation Altitude</b>	2000 m
<b>Cooling</b>	Natural Air Convection

Table 21: Environmental Conditions

## Instruction Manual: Industrial PC

The following distances in millimeters must be maintained on all sides:



### NOTICE



#### Insufficient air supply to the device

Overheating

- Never cover the device completely or operate it in a small, unventilated housing

### 8.6 Temperature test

The values for ambient temperature and humidity were determined under worst-case conditions. The maximum workload of the system was achieved by the BurnInTest from PassMark Software Pty Ltd.

The test ran under 100 % utilisation of:

- CPU
- RAM
- 2D and 3D Graphic (x86 only)
- Brightness of the display

### 8.7 IP Protection Class

The protection class only can be guaranteed under the following conditions:

- The device is installed correctly
- All components and covers of the interfaces are assembled
- Compliance with all environmental conditions

# Instruction Manual: Industrial PC

## 9 Standards and Approvals

The device meets the following requirements.

### 9.1 CE Marking



The device has been tested in accordance with the applicable EU directives and the associated harmonized standards.

### 9.2 RoHS



The device complies with the requirement of the EU Directive RoHS 2011/65/EU.

### 9.3 Electromagnetic Compatibility

The device complies with the requirements of the EU Electromagnetic Compatibility Directive 2014/30/EU with the harmonized standards listed below:

EN 55032: 2015 Class A	Electromagnetic compatibility of multimedia equipment - Emission Requirements
EN 55035: 2017	Electromagnetic compatibility of multimedia equipment - Immunity requirements

### 9.4 Environmentally Appropriate Disposal

**The device must not be disposed of with domestic waste.**



The appliance complies with the requirement of the EU Directive WEEE 2012/19/EU, which is symbolised by the symbol with the crossed-out dustbin.

In order to enable environmentally friendly recycling, the various materials must be separated from one another.

Disposal must be carried out in accordance with the applicable legal regulations.

Component parts	Disposal
Enclosure	Metal Recycling
Electronic	Electronics Recycling
Paper / cardboard packaging	Paper / Cardboard boxes Recycling
Plastic packing materials	Plastics Recycling

# Instruction Manual: Industrial PC

## 10 Technical Support

Despite the highest quality standards and detailed function tests of all our products, daily use of our devices can always lead to damage or failure of a wearing part. The failure of a machine in production costs a lot of money. That is why the Christ company processes complaints as quickly as possible.

You can send the device to us without prior notice. All you need to do is fill out the [repair cover letter](#) and enclose it with the touch panel or IPC so that the service department can start the repair quickly. When the device arrives, it goes through a defined process that clearly documents all processes and makes the respective status traceable. As soon as your panel or IPC is registered in our system, you will receive a confirmation of receipt so that you can also get a precise overview.

Technical Support can be contacted as follows:

Service, Repair and Technical Support

Phone: +49 8331 8371-500

Fax: +49 8331 8371-497

E-Mail: [service@christ-es.de](mailto:service@christ-es.de)

Or directly via the Homepage.

[Christ Service](#)

### 10.1 Device Seal

A device seal is affixed to every Christ device in order to prove whether the device has been opened by a third party. In case of a defect, please do not open the device, but contact our service department. They will discuss the further procedure with you.

# Industrial PC

## Instruction Manual

### Index of Illustration

Illustration 1: Industrial PC	8
Illustration 2: Dimensions Industrial PC	8
Illustration 3: Connection of the power supply	16
Illustration 4: Mounting Industrial PC Step 1	16
Illustration 5: Mounting Industrial PC Step 2	16
Illustration 6: Dismounting Industrial PC Step 1	17
Illustration 7: Dismounting Industrial PC Step 2	17
Illustration 8: BIOS	19
Illustration 9: BIOS COM Port Titanium	20
Illustration 10: BIOS Boot Priority	21
Illustration 11: Argon BIOS Update	22
Illustration 12: Argon BIOS Update successful	22
Illustration 13: Titanium BIOS Update	23
Illustration 14: Titanium BIOS Update successful	23
Illustration 15: Task Manager - enable OBS Client	24
Illustration 16: Start OBS Client	24
Illustration 17: OBS Client System Information	24
Illustration 18: OBS Client Hardware Monitor	25
Illustration 19: OBS Client Settings	25



# Industrial PC

## Instruction Manual

### Index of Tables

Table 1: History	4
Table 2: System overview Argon	7
Table 3: System overview Titanium	7
Table 4: Industrial PC Front	8
Table 5: Dimensions Industrial PC	8
Table 6: Pinout Supply Connector screwable	9
Table 7: Pinout USB 2.0	9
Table 8: Pinout USB 3.0	10
Table 9: Pinout Ethernet	10
Table 10: Pinout WLAN	10
Table 11: Pinout Serial Connector Titanium	11
Table 12: Pinout Serial Connector Celeron N3350 Argon	12
Table 13: Pinout Display Port	13
Table 14: UPS buffer duration	14
Table 15: Power supply	18
Table 16: BIOS	19
Table 17: Mechanical Specifications	27
Table 18: Electrical Specifications	27
Table 19: Power Consumption	27
Table 20: Electromagnetic Compatibility	28
Table 21: Environmental Conditions	28